FOR A GOOD REASON

GRUNDIG

Central Management System

User's Manual

Table of Contents

1. Overview 4
1.1 System Requirements 5
2. Software Installation 6
3. Software Upgrade 12
3.1 Automatic Software Upgrade 12
3.2 Manual Software Upgrade 13
4. Start Up CMS 14
4.1 Starting Up 14
4.2 Login 15
5. CMS Main Window 16
5.1 CMS Icon in the System Tray 21
6. Configure CMS 22
6.1 Setup Groups 23
6.2 Manage the Sites 26
6.2.1 Add/Remove a Site 26
6.2.2 Set up the Site via Device Search 27
6.2.3 Set up the DVR Site Manually 30
6.2.4 Set up the IP Camera Site Manually 31
6.2.5 Set up the CMS Central Site Manually 32
6.3 Set up the File Path 34
6.4 Alert Events 37
6.5 CMS User 43
6.6 Sequence 47
6.7 Login Setting 48
6.8 Network Setting 50
6.9 Log Data 52
6.10 Export or Import Settings 53
7. Operation of CMS 54
7.1 View Live Image / Assign Camera 55
7.2 Camera Setting / Camera Info. 59
7.3 Display Mode 61
7.4 Zoom In/Out Control via Mouse 63
7.5 Sequence Display 64
7.6 Adjust the Image 65
7.7 Playback Recorded Video 66
7.8 Configure the OSD Menu of the Connected Site 74
7.9 Search for Event Videos 76

7.10 CMS Motion Detection 79
7.11 Missing/Foreign Object Detection 81
7.12 Counting Application (PRO Version Only) 84
7.13 Cross Line Alert (PRO Version Only) 86
7.14 Take a Snapshot 88
7.15 2-Way Audio Talk 89
7.16 Instant Record Function 90
7.17 Dome Setting / Dome Control 91
7.18 Schedule Record Function 94
7.19 E-MAP Function 99
7.20 Health Function 105
7.21 Lock Function 106
7.22 Joystick Control Function 107
Appendix A: CMS Player 109
Appendix B: Troubleshooting 118

1. Overview

The Central Management System (CMS) is a powerful and professional centralized monitoring system designed for all range of applications and projects. With CMS, accessing and monitoring multiple surveillance equipments such as DVRs, and Mega-Pixel IP cameras is just a few clicks away. The feature-packed intelligent surveillance offers the professional users with complete and enhanced surveillance experiences.



Features

- **Monitor Multiple Sites** – Supports up to 32 IP devices (The bundled version supports up to 16 IP devices.)
- **Intelligent Surveillance** – Motion, Missing/Foreign Object, Counting and Cross Line Detection
- **SSL Email Notification** – Supports SSL SMTP Server for email notifications
- **Alert Function (LAN Only)** – Sends live/event video clips and messages to the local computer from all connected DVR(s)
- **Device Configuration** – Configures the settings of the connected IP devices
- **Remote Playback** – Allows playback of recorded video stored in the connected DVR(s) or NVR(s)
- **HDD Information** – Displays information of HDDs in the local computer
- **eMap Management** – Keeps geographical marks of surveillance layout on self-selected maps
- **CMS Central** – Easy connection to CMS Central with preset groups/sites
- **Analog & IP Speed Dome control / IP joystick support**

1.1 System Requirements

The following chart shows the recommended computer system:

Operating Systems	Windows XP, Windows Vista, Windows 7	
CPU	Minimum: Intel Core 2 Duo 2.4GHz	Recommended: Intel Core 2 Quad 2.4GHz
RAM Memory	Minimum: 1GB (Connects up to 8 IP devices)	Recommended: 2GB (Connects up to 16/32 IP devices for bundled/PRO version)
HDD	Minimum of 80GB HDD space is required if users are recording video to the local machine.	
Video Card	Minimum: Graphics card with more than 64MB RAM	Recommended: Graphics card with 512MB RAM
Ethernet	Minimum: 100 BaseT	Recommended: Gigabit LAN
Tested Setup	CPU: Intel® Core™ 2 Quad CPU Q6600 @2.4GHz, RAM: 2GB, OS: WinXp, Display: NVDIA GrForce 8400GS 512M, Ethernet: Gigabit HUB	

NOTE: For Live viewing of more than 16 IP devices, users need to lower the camera resolution and change the compression method to MPEG4 or MJPEG.

NOTE: If the operating system is Windows Vista, some functions (such as Record, Auto Reboot, etc) will not work properly due to User Account Control (UAC). Follow the steps below to solve this problem.

Step 1. If a previous version of CMS is installed, export setting files of CMS servers (1~4) before installing the new version CMS.

Step 2. Due to UAC, the user account in Windows Vista cannot properly run the applications that will write in the "C:\Program Files\" folder. Therefore, CMS will be installed in the "C:\" folder instead.

Step 3. Once the new version CMS is installed, import the setting files back to CMS servers (1~4).

2. Software Installation

Follow the steps below to install CMS to the local computer.

Step 1. There are 2 ways to start the installation.

Option 1. Download the compressed file and extract it. Click on the CMS_Setup.exe file to start the installation.



NOTE: Some antivirus software might report false alarm when users move the mouse cursors over the CMS_Setup.exe file. Right-click and select <Always ignore> in order to continue the installation.



Option 2. If CMS will be installed via a CD, the installation will start up automatically when the CD is inserted. The <CMS Setup Menu> window will be displayed. Choose <INSTALL CMS> to start installing CMS. Choose <CMS USER'S MANUAL> to open the user's manual. Choose <EXIT> to exit the <CMS Setup Menu>.

NOTE: If an older version of the CMS had been installed onto the local computer, a message box will be prompt. Click <OK>

to uninstall the previous version.

After clicking <OK>, an <CMS Installation Uninstall: Confirmation> dialog will be displayed. Click <Uninstall> to uninstall the older version and continue with the next step.

CMS Installation Uninstall: Confirmation
This wizard will uninstall CMS Installation from your computer. Click Uninstall to start the uninstallation.
Uninstalling from: C:\Program Files\CMS
Cancel
Nullsoft Install System v2.25
Uninstall

Step 2. Select the components that are going to be installed. It is strongly recommended to select the <Start Menu Shortcuts> to create shortcuts in the Start Menu and on the Desktop. Otherwise whenever the program is to be opened, it will have to be found under the path: "\CMS\EXE\CMS.exe". Click <Next> to go to next step.


CMS Setup: Installation Options
Check the components you want to install and uncheck the components you don't want to install. Click Next to continue.
Select components to install:
Microsoft VC 2008 SP1 Redistributable Pack
CMS (Required)
Start Menu Shortcuts
NTP (Network Time Protocol) Server
Default Setting (Old setting will be deleted!
Ext2Fsd (ext2 file system driver for Windo
Space required: 124.3MB
Cancel
Nullsoft Install System v2.45
Next >

The components of the CMS Installation Setup are:

a. Microsoft VC 2008 SP1 Redistributable Package: This is an upgrade package required for correctly running CMS.
b. CMS: The CMS main program must be installed (default).
c. Start Menu Shortcuts: Check the box to create shortcuts in the Start Menu and on the Desktop.
d. NTP (Network Time Protocol) Server: Check the box to install the NTP server.
e. Default Setting (Old setting will be deleted!): Check the box to load default setting, or uncheck it to load the old setting of previously installed CMS.

f. Ext2Fsd (ext2 file system driver for Windows): Check the box to install the driver in order to be able to read raw files in DVR HDD.

NOTE: If users have already installed the EXT2IFS driver and software, please uninstall it beforehand, for there might be confliction occurs while installing the Ext2Fsd driver during CMS installation.

Step 3. The CMS main program will be the first program to be installed. Choose a folder to install the CMS or it will be installed to a default destination folder "\CMS\". Click <Install> to start the Installation; or click <Back> to go back to the previous step.


CMS Setup: Installation Folder
Setup will install CMS Installation in the following folder. To install in a different folder, click Browse and select another folder. Click Install to start the installation.
Destination Folder
C:\Program Files\CMS
Browse...
Space required: 42.5MB
Space available: 3.5GB
Cancel
Nullsoft Install System v2.25
< Back
Install

Step 4. The NTP Server will be the next program to be installed. The NTP Server enables the local computer, which is running the CMS, to become a central NTP Server for the connected DVR(s) so the time for the local computer and the connected DVR(s) is synchronized.

Click <OK> to start installing the NTP Server.


CMS Setup
NTP(Network Time Protocol) is the abbreviation of Network Time Protocol which is designed for timesync cross the network.
The following web site would be a good start point if you wanna get know about this topic.
http://www.ntp.org/
OK

Step 5. Click <Close>, and the Software Installation is completed.



NTP Service (Server)

The NTP Service (Server) enables the local computer, which is running the CMS, to become a central NTP server for the connected DVR(s) so the time for the connected DVR(s) and the local computer is synchronized.

To do so, the IP address of the local computer is needed.

Go to **Start** menu, select **Run**.



Type in **cmd** and click OK.



Type in **ipconfig** to get the IP Address of the local computer. Write down the IP address on a piece of paper for later use.


C:\WINDOWS\System32\cmd.exe
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.
C:\Documents and Settings\Owner>ipconfig
Windows IP Configuration
Ethernet adapter Local Area Connection:
Connection-specific DNS Suffix . :
IP Address. . . . . : 192.168.7.122
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . : 192.168.7.254
C:\Documents and Settings\Owner>_

After the IP address is found, set up the connected DVR(s).

First, go to <Main Menu> → <System Setup> → <Date/Time> → <Time Zone> to set up the time zone. To find out the local time zone, please visit www.greenwichmeantime.com

NOTE: The <Time Zone> must be set or the <Network Time Protocol Setup> will not be accessible.

After entering the local time zone, the <Network Time Protocol Setup> option will be accessible. Go to <Main Menu> → <System Setup> → <Date/Time> → <Network Time Protocol Setup>, and the following menu will be displayed.

Network Time Protocol Setup	
NTP Server	time.nist.gov
Automatically Time Sync	On
Manually Time Sync	No

In this example, the NTP server should be set to "192.168.7.122" which is the IP address of the local computer. After the NTP server is set, select <Yes> for <Manually Time Sync> to immediately synchronize the time with the local computer. The time synchronization can also be updated periodically. Select <On> for <Automatically Time Sync> and the time will be automatically synchronized once an hour.

3. Software Upgrade

The CMS software can be upgraded automatically or manually. Refer to the following sections for details.

3.1 Automatic Software Upgrade

To enable an automatic software upgrade, right-click on the CMS icon in the system tray and check "Auto Upgrade". If automatic software upgrade is enabled, CMS will connect to the FTP Server and check for upgrade once a month. If no upgrade is available, CMS will continue normal process. If upgrade is detected, please follow the steps below to proceed.

Step 1. A message box will pop up to inform the user that there is an upgrade available.



Click <OK> to download the upgrade software and continue to the next step. Otherwise, click <Cancel> to abort and continue to normal CMS process.

Step 2. Choose a destination folder to save the file. Then a window will pop up and show the downloading status.


Download
Abort
Source: /CMS_Software_update/upd_CMSs/CMS_Release_bff_0.2.0.zip
Target: C:\Documents and Settings\chienwen\MY_TEST.zip
574 KB from 7852 KB transferred (25 KB/sec). Remaining time: 4 min

Click <Abort> to terminate the download and CMS will be started as

usual.

Step 3. When the download is completed, the installation of the new version of CMS can be started following the same procedures as described in section ***Software Installation***.

NOTE: If the upgrade file is not completely downloaded, an error message will be displayed as shown below.



NOTE: A release note will also be downloaded together with the setup file. The following message will be displayed to show the file path where the release note is saved.



3.2 Manual Software Upgrade

To manually upgrade the software, click on the <Setting> button and click on <Software Upgrade> at the bottom. Then follow the steps in the previous section to complete the download and installation.



4. Start Up CMS

Before starting up CMS, PRO version users have to insert the USB Dongle. Otherwise functions especially designated for PRO version will not be available.

NOTE: If the version of USB Dongle is an older version comparing to CMS, an error message will be displayed to request users to insert the correct version of USB Dongle.

NOTE: If USB Dongle is unplugged while running CMS, a warning message will be displayed. Users have to re-insert the USB Dongle or CMS will be automatically shutdown in 10 seconds.

There are 3 ways to start CMS. Note that method A and B are only available if the "Start Menu Shortcuts" component is installed. Please see section ***Software Installation*** for more information.

Method A: Click Start menu and select Programs; find "CMS" from the listed programs.
Method B: Double-click on the shortcut icon on the desktop.
Method C: Go to "\CMS\EXE\" and double-click on CMS icon.

4.1 Starting Up

If CMS is started for the first time, select a desired language for the interface. The available languages are listed in the scroll box. Click <OK> to confirm the selection.



If the system memory or CPU frequency is less than the requirements, the error message shown below will be displayed.





4.2 Login

The default User Name & Password are listed below.

User Name: admin
Password: 1234



Check <Save user name and password> to save time of entering the username and password every time CMS starts. Click <OK> to login.

Username and password accounts can be added or removed under the <CMS User> tab in <Setting> configuration window. Refer to the *CMS User* section for more information.

NOTE: If a wrong username or password is entered for 3 times, an error message will be displayed, and CMS will be closed automatically after <OK> is clicked. Restart CMS to enter the correct username and password.

After logging in to CMS, error messages might be displayed under the following conditions:

1. For bundled version users, an error message will be displayed if there are more than 16 IP devices added to a group from the previous settings.
2. When the version of CMS USB Dongle inserted does not match the version of CMS, an error message will be displayed if there are more than 16 IP devices added to a group from the previous settings.
3. For PRO version users, an error message will be displayed if there are more than 32 IP devices added to a group from the previous settings.

Users have to insert a correct version of CMS USB Dongle or decrease the number of IP devices to be within the bundled version constraint.

5. CMS Main Window

After starting up CMS, the main window of CMS will be shown as in the picture below. The name of each button is indicated as follows.



1	Display Mode: 4-windows, 16-windows, 25-windows, 36-windows, 49-windows, 64-windows, 8-windows, 10-windows, 13-windows, Sequence, Full Screen
2	Left to Right: Live, Playback, CMS Player, Snapshot, Emap
3	Left to Right: Schedule Record, Setting, Health, Lock, 4:3 Display
4	Site Tree
5	Bandwidth – Normal/Dual Streaming
6	Left to Right: Audio, Smooth Adjustment, Deflicker, Recording
7	HDD Info

The usage and function of each button will be briefly described as follows.

Display Mode

Click on any <Mode> icon to view the **image** in a multiple window mode. The selections are 4-windows, 9-windows, 16-windows, 25-windows, 36-windows, 49-windows, 64-windows, 8-windows, 10-windows, and 13-windows. Refer to section ***Display Mode*** for more details on operation.

Click on <Sequence> to start displaying the sequence list. See section ***Sequence Display*** for more detailed information.

Click on <Full Screen> to extend the current viewing grids to full screen. Hit <Esc> to exit.

Live

Click on the <Live> icon to view the live video. Note that after viewing the recorded video, this button needs to be clicked to switch back to live mode.

Playback

Click on the <Playback> icon to view the recorded video stored in the HDD of the connected DVR. Please refer to section ***Playback Recorded Video*** for more information about playing back the video.

CMS Player

Click on the <CMS Player> icon to start up the CMS Player. CMS Player is an enriched version of the standard DVRPlayer. Please refer to **Appendix A** for more information.

NOTE: When CMS is terminated, CMS Player will also be ended at the same time.

Snapshot

Click on the <Snapshot> icon to save a snapshot of the current window(s). Refer to section ***Take a Snapshot*** for detailed information.

Emap

Click on the <Emap> icon to open the E-Map program. The E-Map is a program that allows users to illustrate the positions of the cameras on a self selected image.

Schedule Record

Click on the <Schedule Record> icon to schedule the recording time frame for the sites.

Setting

Click on the <Setting> icon to set up the configuration. Refer to section ***Configure the CMS*** for detailed information.

Health

Click on the <Health> icon to see the HDD information of the connected DVR(s). The data will be updated every 5 minutes. The following picture is an example. See section ***Health Function*** for more detailed information.


Health Status (Refresh Rate = 5 min)
Site[01]
Device Name | Internal/External | Total size | Active/NonActive | Temperature
BF2345GR | Internal | 148GB | Active | 38
Site[03]
Device Name | Internal/External | Total size | Active/NonActive | Temperature
BM4567GR | Internal | 487GB | Active | 31

NOTE: If more than half of the connected devices are not our products, a warning message as below will be shown and CMS will be closed automatically.



Lock

Click on the <Lock> icon to lock CMS to protect the works on CMS when users need to be away from the computer for a while. This function is the same as the computer's screensaver. See section ***Lock Function*** for more detailed information.

4:3 Display

Click on the <4:3> icon to change the screen display to 4:3 ratio. Click on the icon again to return to the original aspect.

Site Tree

Site tree displays sites that are currently being viewed. If the connection to a certain camera failed, there will not be any image displayed on its assigned grid. Right-click on the "site" and click <ReConnect> to try to establish the connection to the site. The <DisConnect> option allows users to only disconnect a certain site.



Users can also rename the camera directly by right-clicking on the camera and selecting <Rename>. The new name will be shown on the upper left corner of the camera's assigned grid. Note that group and site cannot be directly renamed at the site tree.



By right-clicking on the group icon, the options shown as on the right allow users to expand or hide the site tree at once.



If the group is connecting to CMS Central, the right-click options are as shown on the right. Select <Reconnect> to re-establish the connection to CMS Central. Select <Talk> to initiate a two-way communication between CMS and CMS Central.



Bandwidth – Normal/Dual Streaming

For different networks with different bandwidths, two streaming options are provided – normal streaming and dual streaming. For users who are using high-speed networks, normal streaming will be a recommended choice. Depending on the HDD capacity and network usage, set it to high, middle, or low bandwidth.

For networks with limited bandwidth, dual streaming will be a better choice. It enables coexistence of high quality streaming at a local DVR site and lower quality streaming but faster transmission for a CMS site. To select dual streaming, click on the bandwidth icon and the icon will change its colour. Then users can furthermore choose different bit rates to adjust for the best displaying quality.

The setting will be applied immediately, and is going to be saved for CMS next startup.

NOTE: Dual streaming will only be available when DVR's total PPS is set to one-half of the max PPS, for example, set 30PPS for D1 recording. The reserved half of the max PPS will be handling the low rate streaming for transmission to the remote monitoring site.

Audio

Click on the audio button to switch on/off the audio.

NOTE: Switching ON/OFF the audio on CMS will not affect the audio setting of the connected DVR(s).

Smooth Adjustment

Click on the smooth adjustment button to switch on/off the smooth adjustment function. Switching on the function helps to give the image more sharpness.

Deflicker

Click on the deflicker button to turn on/off the deflicker function. Switching on the function helps to avoid gleaming of images.

Recording

Click on the recording button to start recording videos of all connected sites. The recorded data will be stored in the preset file path specified in settings.

HDD Info

The pie chart displays the HDD information. This is especially useful when users use CMS to record the video to the local computer.

Scroll down the menu to see the information of all the HDD(s) installed on the local computer, such as C drive, D drive...etc. The blue part of the pie chart indicates the used space, and the yellow part indicates the available space.

The information will be updated every 30 seconds. If file circular is enabled, the circulation will as well be updated every 30 seconds.

5.1 CMS Icon in the System Tray

When CMS is started up, the CMS icon will always be shown in the system tray. Right-click on CMS icon and the menu items will be as shown on the right.



If <Minimize To Tray> is checked, CMS window will shrink to CMS icon in the system tray when it is minimized. The task button will also disappear.

To restore the CMS window, click on the CMS icon and the task button will appear again. Then click on the task button to maximize CMS window. Alternatively, right-click on CMS icon and select <Open CMS> and CMS window will be restored.

Right-clicking on CMS icon and selecting <Help> will display the CMS user's manual.

Details of <Auto Upgrade> are described in section ***Automatic Software Upgrade***; <Alert Info.> is explained in section ***Alert Event***; <Show joystick function> and <Joystick control (On/Off)> are introduced in section ***Joystick Control Function***.

6. Configure CMS

CMS supports up to 10 groups, with up to 32 IP devices per PRO version and up to 16 IP devices per bundled version. The following sections will guide users to set up CMS step by step.

Click on the <Setting> icon and a window as in the picture below will be displayed.



NOTE: The configuration in the "Groups" tab and the "Import" function will not be saved when CMS is detecting a network connection or is connecting to some sites. Error messages will be shown to inform the users.

NOTE: When the setting of a connecting group or sites is changed, users can directly click on <Save and Connect> to re-establish the connection.

6.1 Setup Groups

Up to 10 groups can be set in CMS. This section guides users to add or remove a group, and also shows users how to set a "start group".

Add a group

Click the button to add a group. Double-click on the group to rename it.



The other way to add a group is to right-click on <Groups>, and select <Add a group>.

Set Start Group

The “Start Group” is the group that will be connected after starting up CMS.

Right-click on the group to be set as the“start group”, and select <Set as start group> from the pull-down menu.



NOTE: If a group is set as the “start group”, the icon will be changed as shown in the figure above.

Expand /Hide a Group

There are two ways to expand or hide a group. One way is to use the buttons; the other way is to right-click on the group and select <Expand> or <Hide> from the pull-down menu.



Remove a Group

To remove a group, click on the group to be removed, and then click the button directly to remove the group. The other way to remove a group is to choose <Remove> after having right-clicked the group.



6.2 Manage the Sites

The following sections are instructions for the management of the sites, including adding or removing sites and their configuration.

6.2.1 Add/Remove a Site

This section describes how to add or remove a site.
The PRO version CMS supports up to 32 IP devices which can be added to each group. If more than 32 IP devises are added, an error message will be displayed.

NOTE: The bundled version supports only 16 IP devices per group. If more than 16 IP devises are added, an error message will be displayed as shown below.



Choose a group to add a new site. Click the button to add a site to this group. The next section will show how to set up the site step by step.



The other way to add a new site to a group is to right click on the group, and select <Add a site>.

Remove a site

To remove a site, click on the site that is to be removed, and click the button directly to remove the site.



The other way to remove a site is to right-click on the site, and select <Remove> from the pull-down menu.

A new site can be a DVR, an IP Camera, or a CMS Central. The number of sites equals the total number of the DVRs and IP Cameras. However, the CMS Central can only be individually added to a new group all alone by itself. The following sections will show how to set up the configuration of the sites.

6.2.2 Set up the Site via Device Search

There are two ways to set up a site. The simple way is via Device Search.

CMS is able to search for IP addresses of DVRs, IP Cameras, and CMS Centrals connected to the PC's LAN network. The ports used for device search are 6666 and 6667. Please make sure that these two ports are not in-use nor blocked by firewall or virus scan software.

Follow the steps below to search for DVR(s) or IP Camera(s):

Step 1. If there are DVRs, IP Cameras, and/or CMS Centrals installed in the LAN network, CMS can search for IP addresses of the installed devices. Click the Search button (**on the bottom right**) to open the Search window.



Step 2. The list will show the IP addresses of DVR(s), IP Camera(s), and CMS Central(s) available in the LAN network. Select from the list and **Double Click** on the IP address to add it to a site. Then enter the user name and password of the selected DVR or IP Camera. For CMS Central, refer to section ***Set up the CMS Central Site Manually*** for further configurations.



NOTE: The Device Search function can only be used to search for addresses within the same LAN. For example, if the local computer uses an IP address of 192.168.**1**.5, and a connected DVR has an IP address of 192.168.**1**.7, CMS will be able to find the IP address of the

network such as 192.168.**3**.6, CMS (whose IP is 192.168.**1**.5) will not be able to find the IP address of the DVR in another LAN network.

Search UPnP devices

Check the box in front of "Search UPnP Devices" and click <Refresh> to start searching for UPnP devices within the LAN network. While the search is in process, the <Refresh> button and the "Search UPnP Devices" option will be grey and cannot be clicked or selected, in addition the window cannot be closed. The <Refresh> button will be changed to <Search UPnP> to remind users of the status. Everything will work only after the searching process is done. If the user double-clicks on the list or tries to close the window, a warning message will be shown.

6.2.3 Set up the DVR Site Manually

If the detailed information (IP address, port, username, and password) of the connected DVR is provided, a site can be set up manually.

Add a new site and enter the Site name, IP address, Port, Username, and Password. Select <DVR> and click <SAVE> to complete the setting.



NOTE: If the entered Username and Password is a user account instead of an administrator account, the same DVR account restriction will be applied. When a user account accessed a function that is restricted, a warning message will be displayed.

If the DDNS information of the DVR is known, the DDNS data can be used to set up a site. Check the box <(D)DNS> circled below, and type in the DDNS data. Click <SAVE> to complete the setting. An example of the DDNS address looks like: *********.ddns.iview-ddns.com**



6.2.4 Set up the IP Camera Site Manually

If an IP Camera is going to be added to CMS, the required information includes the IP address, port, username, password, and brand/model type of the IP Camera. Enter the data and select <IP Camera> as circled below. Then choose the <Model> and <Stream Type> of the IP Camera. Click <SAVE> to complete the setting.



6.2.5 Set up the CMS Central Site Manually

If users want to add a CMS Central site, it has to be the only site in the group. Select <Central> as circled below. The site name will be automatically changed to "Central" and it cannot be renamed.



A setup window will pop up as shown below. Input the CMS Central's IP, port, username and password. Then click on <Testing Central Connection> to test if the connection to CMS Central is successful. The testing result will be displayed on the right. Note that "()" next to site 2 of CMS Central means site 2 is not connected by CMS Central. Users can check or uncheck in front of the sites to select whether to display their videos. Click <OK> to confirm and save the setting.



NOTE: If the IP address of CMS is not added to the White List of CMS Central, a message "Not In White List!" will pop up.

NOTE: If the IP address of CMS is added to the Black List of CMS Central, a message "In Black List!" will pop up.

For further details of CMS Central settings, please refer to the user's manual of CMS Central.

When users wish to edit the settings of the CMS Central site, select <Central> again or right-click on the Central site and select <Set Central> to pop up the Set Central window.

6.3 Set up the File Path

The file path menu defines stored destination of snapshot, archive files, and recorded videos. It is recommended to use the default folders.



Record Path

The recorded videos can be stored in more than one folder. Click on <Advance> and the following window will be shown.



The number of the selectable folders equals the number of HDDs the PC connects to, excluding the HDDs with a capacity less than 1GB. Check the "Enable" box and click <Browse> to set more destination folders. Each folder should be from a different HDD or an error message will be displayed. Note that if a HDD with less than 1GB capacity is selected, an error message will be shown. Clicking on <Clear All> will delete all folders except the first preset folder.

In each folder, subfolders will automatically be created with the folder name "RecordFolder********" (******** represents an 8-digit serial number). Each subfolder can store up to 500 videos. Once a subfolder is full, a new subfolder with a subsequent number will be created and new files will be stored to the new subfolder.

Circular Function

The <Circular> function is used to adjust the HDD space usage of CMS. For example, when the threshold is set to 1GB, and there is a 20GB free disk space remaining in the HDD, CMS can only access the HDD to no more than 19GB. When the free disk size is smaller than threshold:

1. If the circulation of files is performed for the first time, CMS will start to overwrite the earliest recoded data. Next time when CMS starts up, the circulation of files will continue from where it was up to.
2. If the destination folders are reset, new folders will be created to store new files. The old files will be deleted and rewritten with new files.

Record Videos from IP Cameras to Remote Network Disks

When videos from IP cameras will be recorded to a remote network disk, the DRV file is going to be stored under a temporary folder "\CMS\TEMP_REC\" if the file size is less than 100MB. Once the file size reaches 100MB, the file will automatically be transfered to the designated remote network disk.

If the recording is interrupted (either connection reset, disconnected, stops recording, etc), a progress bar will be shown to inform users that the DRV file is being transfer to the designated remote network disk.

NOTE: For CMS servers 2~4, the temporary folders will be named as TEMP_REC2, TEMP_REC3, and TEMP_REC4.

Data Life Time

If users check the box in front of "DLT" to enable the Data Life Time function, the duration in days has also to be defined. When the Data Life Time function is enabled, CMS will check the file edit time of the recorded video files in a "Record Path" and any video files exceeding the defined duration will automatically be permanently deleted.

Snapshot Type

CMS has a snapshot function, and the file type for snapshot can be defined here. Note that if more than one type is selected, take 2 types for example, then each snapshot is saved to 2 types of files. They are the same image, but in different formats. For instance, if Bmp & Tif are selected and the snapshot is taken, two types of image files of the same snapshot image will be created.

6.4 Alert Events

The alert function enables the connected DVR(s) to send alert signals to CMS within the network. This section describes how the alert function works.

Setting up the alert function

Step 1. Find the IP address of the local computer.

Go to **Start** menu, select **Run**.



Type in **cmd** and click OK.



Type in **ipconfig** to get the IP Address of the local computer. Write down the IP address on a piece of paper for later use.


C:\WINDOWS\System32\cmd.exe
Microsoft Windows XP [Version 5.1.2600]
(C) Copyright 1985-2001 Microsoft Corp.
C:\Documents and Settings\Owner>ipconfig
Windows IP Configuration
Ethernet adapter Local Area Connection:
Connection-specific DNS Suffix . :
IP Address. . . . . : 192.168.7.122
Subnet Mask . . . . . : 255.255.255.0
Default Gateway . . . . . : 192.168.7.254
C:\Documents and Settings\Owner>_

Step 2. Set up the <Alert Notification Setup> on the connected DVR(s). The <Alert Notification Setup> allows users to send alert notifications to the CMS program which had been installed to the computer.

Alert Notification Setup	
Alert Configuration Set	1
Alert Notification	OFF
Alert IP	192.168.7.122
Alert Port	999
Alive Interval	120 Sec

- Alert Configuration Set
  <Alert Configuration Set> provides 3 combinations of Alert Notification, IP, and Port. Users can match the connected DVR to up to 3 different CMS servers.

- Alert Notification
  4 options are included in this item; <OFF>, <Event>, <Alive>, and <Both>.
  <**OFF**>: The Alert Notification is turned off.
  <**Event**>: When the alarm is triggered, the DVR will send an alert message to CMS.
  <**Alive**>: The DVR will send an alive message to CMS every *N* second just to show that the connection between the DVR and CMS is in effect. The time interval *N* can be adjusted in <Alive Interval>.
  <**Both**>: This enables the DVR to send both Event and Alive alert messages to CMS.

- Alert IP
  The Alert IP must match the IP address of the local computer. In this example, the IP address of the local computer is 192.168.7.122.

- Alert Port
  The Alert Port is the port used for sending and receiving alert signals. Choose any port that is not restricted by the network. The ports for both connected DVR and CMS Alert **must be the same**. In this example, the port is set to 9999.

NOTE: If 2 configuration sets are corresponding to 2 different CMS servers, each CMS server must have its own unique port number.

- Alive Interval
  Time interval (1 to 255 sec) between each alive message can be set here.

Step 3. Set up the Alert of CMS.

Click on the <Setting> icon and go to Event tab to set up the port. Port 9999 is used in this example. Select <ON> to enable the alert function. <Event Full Screen> is used to display full screen of the alerted channel. Select <ON> to activate this function, or <OFF> to deactivate it. <Event Recording Duration> is for users to define recording duration of event videos, when schedule is set and/or when motion recording is enabled. In addition, users can send a notice to a specific email via a SMTP server by selecting <ON> next to <Enable> under "Email Notice". If the email server requires SSL, select <ON> next to <SSL>. Then enter all required SMTP information. If the format of the email address is entered incorrectly, an alert message will be shown on the screen.



NOTE: If users reconnect or disconnect the sites, the list of the event full screen will be cleared.

NOTE: Once the list of the event full screen finishes playing, the window will return to the former viewing status**.**

Step 4. Alert Action

The connected DVR sends 4 types of alert message (State) to CMS: Alive, Alarm, Motion, and Video Loss. Alive messages are sent when the notification option is set to <Alive> or <Both> in the connected DVR. Alarm, Motion, and Video Loss messages are sent when the notification option is set to <Event> or <Both> in the connected DVR.

Viewing the alert events

When an alert is triggered while the alert function is enabled, CMS icon shown in the system tray will change to the Alert icon to indicate that an alert is being triggered. Right-click on the CMS icon and choose <Alert Info> to show the Alert Info window. Alternatively, double-clicking on the blinking CMS icon can also display the Alert Info window.

Users can click on the <Save> button to save the alert information list.



NOTE: The maximum number of items which can be kept on the alert list is 1,000. When the list reached 1,000 items, the earliest alert messages will be deleted while the new ones are being saved.

Double-click on the Event Messages (Alarm, Motion, or Video Loss) to view the event video in full screen. If the DVR sending the Event Messages is not currently connected to CMS, a message box will be displayed. Connect the DVR and the event video will be available.

Icons of alert types, as listed below, will be displayed at bottom-left of the grid.

	Motion		Alarm
	Cross Line		Video Loss

NOTE: The Alert function works ONLY within LAN network. (Please refer to the note of the Search function)

NOTE: If the alert event has not yet been added to the database of the DVR, a warning message will be shown to inform the users.

6.5 CMS User

The <CMS User> is for the management of user accounts in CMS. Users can set users' account information and privileges. The default username and password are: **admin** and **1234**.



NOTE: Only users among the <Admin> group have the privilege to change the settings in <CMS User>.

To add a user, users must first add a group. Right-click on <User List> and select <Add Group> from the pull-down menu.



After the group is added, the first user account of the group will also be created. Users **MUST** set the password for this account before users can go to the next step.



Right-click on <NewGroup01> to add a user, remove a group, or rename the group.



NOTE: The account currently used to login cannot be deleted. An error message will be displayed.

Right-click on <Group01User01> to remove a user or rename a user name.



The <Group Attribution Setting> is for setting up the privileges of the selected user. Users can give each user account different privileges by configuring this function.



After entering the <Group Attribution Setting>, the following diagram will be shown. Select a user account in <Select CMS Group>, and users can click on the buttons to enable or disable its privileges.



- Purple buttons are CMS menu controls including: Playback, Player, Emap, Schedule Record, Setting, and Lock.
- Grey buttons are site controls including: ReConnect\DisConnect, Record, Configuration, Event, and Camera Setting.
- Yellow buttons are camera controls including: Sequence, Rename, Dome Setting, Dome Control, Remove, and Sound Notification.

Each camera can be set to enable/disable Live, Play, or Record function individually after clicked on <Advance Setting>. Refer to the following figure for details.



NOTE: The preset is 20 cameras for all sites. The real number of cameras per each site will not be detected.

NOTE: These settings will affect the whole operation of CMS. Please be very careful while configuring the settings.

Next time when users login, users can choose to enter CMS either as the admin or users.

6.6 Sequence

This function is used to set the displaying sequence. Before starting sequence display, users need to add channels to the sequence list. Right click on any channel and select <Add to Sequence> to add, or <Remove from Sequence> to remove. Note that when the channel is added to the sequence, a capital "S" will be shown on the icon.



After the channels are added to the sequence, click on the <Setting> icon and choose <Sequence> to set up the sequence. Under the <Sequence Setup> option, users can set up the dwell time (1 to 120 seconds), and split mode (1*1, 2*2, 3*3, 4*4, or 5*5). <Sequence Order> lists the channels that have been added to the list in order. Click <Save> to save the settings.



Click <Clear Sequence List> to empty the list. A message window will be shown for confirmation.



6.7 Login Setting

Users can edit options regarding login settings in this section. Administrator´s username and password are required to edit the setting.



As shown in the above picture, the box marked "1" is where users can enter a set of username and password to be used for auto login. The "Verify" button can help users to check if user name and password are correct. The following messages boxes will show to inform the result of verification.

Correct



Wrong



The box marked "2" contains the options regarding automatic actions. Clicking the first option "Start CMS when Windows starts up" to request the computer to open CMS in the mean time when the system startup. Note that the other two options "Auto Login" and "Auto retrieve Live image When Login" will be checked at the same time. Nonetheless, it is still users' choice to determine the favorite setting.

The following message will be shown when CMS is auto opening after the system started up. Click "Cancel" can terminate opening CMS.



Click the second option "Auto Login" to automatically login when CMS starts. Remember to enter and verify username and password in box 1.

Click the third option "Auto retrieve Live image When Login" to automatically connect to the sites in the start group when CMS starts. Detection of internet connection will be performed before hand and the following message will be displayed. Click <Stop> to terminate the detection and AutoLive will not be initiated.



6.8 Network Setting

CMS provides the option of connection via a proxy server for DVRs and Video Servers (D7521). Click <Network> tab and setting items are shown as below.



If users wish to create the connection via a proxy server, check the box "Use a proxy server for your CMS connection." Then enter the IP address and port of the proxy server. Enter username and password if authentication is required.

NOTE: CMS supports the most common authentication keys "Digest" and "Basic". The authentication will be automatically detected and performed.

Check the box "Bypass proxy for local address" to disable connection via the proxy server for local LAN network.

The <Advance> button allows users to edit an exception list where addresses in the list will not be connected via the proxy server. The addresses can be subnets. Refer to the picture on the right for an example of the exception list.



NOTE: All functions of the proxy server are tested with the most common "Squid Proxy Server". Some other proxy servers may not

work properly.

6.9 Log Data

The step by step operation of CMS will be recorded by CMS log function. Refer to the following picture for data kept in the log file.



The list will display 1,000 items with latest ones shown at the bottom. The list can store up to 10,000 items in circulation, which means the oldest ones will be deleted when the number of items exceeds 10,000.

Save button

Click this button to save the log file to a desired destination.

Previous button

Click this button to show previous 1,000 items.

Next button

Click this button to show next 1,000 items.

On the right hand side of the window, users can choose whether to show and/or save disconnection logs. Check the box next to "Pup Up Disconnection Log Window" to display disconnection logs. If users wish to save disconnection logs, check the box next to "Save Disconnection Log" and click <Browse> to set up the directory folder and the file name of the disconnection log file.

6.10 Export or Import Settings

The export/import function provides users the option to backup the settings as needed.



To export the configuration, click <Export> and select a directory to save the *.zip file in.

To import a previously saved configuration, click <Import> and find the *.zip file that was previously saved.

NOTE: An error message will be displayed if the IP devices set up for the imported configuration exceed the allowable number, which is 16 for bundled version and 32 for PRO version.

NOTE: After a setting is imported and saved, the imported setting will be loaded immediately and CMS will reconnect to the sites in the live group.

7. Operation of CMS

For the bundled version CMS, users can open up to 2 CMS instances simultaneously. Furthermore, PRO version CMS can have at most **4** CMS instances opened simultaneously. If the PC is connected to more than one monitor, for example 4, then the PC can open up to 4 CMS instances at the same time on the 4 different monitors respectively. However the processor and RAM of the PC will limit the number of CMS instances as well. Note that all monitors have to be set to the same displaying resolution.

NOTE: When bundled version users open a 3rd CMS instance, an error message as shown below will be displayed.



CMS multiple instances limitation according to the PC:

Dual Core or Hyper-Threading	RAM ≥ 512MB	Open 1 CMS
	RAM ≥ 1GB	Open up to 2 CMS
	RAM ≥ 1.5GB	Open up to 3 CMS
	RAM ≥ 2GB	Open up to 4 CMS
Single Core and Frequency > 2.0GHz	RAM ≥ 512MB	Open 1 CMS
	RAM ≥ 1GB	Open up to 2 CMS
	RAM ≥ 1.5GB	Open up to 3 CMS
	RAM ≥ 2GB	Open up to 4 CMS
Single Core and Frequency ≤ 2.0GHz	RAM ≥ 512MB	Open 1 CMS

NOTE: It is recommended to keep the connected channels within 512 channels if multiple CMS instances are opened.

Network Connection Detection

CMS will auto detect network connection status. If CMS lost network connection, the following error message will be displayed.


Disconnected from network!
Live images will be automatically retrieved when network connection is restored.
Please wait...
Stop

When CMS detected the restore of network connection, the error message will disappear. Click on <Stop> to cancel this function.

7.1 View Live Image / Assign Camera

Users can view live video or connect to the connected DVR using the live button. Click on the <Live> button to see the live view.

Connect/Reconnect/Disconnect the Sites

If the connection between CMS and the connected site has been interrupted, users can reconnect the site by right clicking on the **Site** in the site tree and select <ReConnect> from the pull-down menu. Users can also disconnect specific sites by selecting <DisConnect> from the pull-down menu.



NOTE: For Live viewing of more than 16 IP devices, users need to lower the camera resolution and change the compression method to MPEG4 or MJPEG.

Auto Detection of Disconnected Sites

CMS will automatically detect if any sites that are connected at the beginning are disconnected for some reason later on in every 3 minutes. A list will be shown (as on the right) when there are sites detected to be disconnected.



The list can be saved as a TXT file by clicking on <Save> at bottom left.

Check the box to disable pop up of the disconnection list. To enable it again, click on the <Setting> icon and go to the <Log> tab.

NOTE: Besides auto-reconnect, a progress bar will be displayed as below. The connecting process will take at most 30 seconds.



Auto-Reconnect of Specific Disconnected Sites

CMS will automatically reconnect to specific disconnected sites every 7 minutes. Refer to the following table for all cases.

Situation	Auto-Reconnect
Sites that are not connected at the beginning:	Yes
Sites that are disconnected manually	No
Sites that are connected at the beginning but disconnected for some reason later on	Yes

Display Colour of Camera Titles

There are three different display colours for camera titles, Red, White, and Green. The following chart shows the meaning of these three different colours.

Red	The connected site is a DVR currently recording.
White	1. The connected site is a DVR **NOT** recording. 2. The connected site is an IP Camera or a Video Server.
Green	CMS is remotely playing back videos from connected sites.

Assign a Channel/Site to Certain Window(s)

CMS allows users to assign any channel/site in the site tree to any grid of CMS main window. Follow steps below to complete assignment.

Step 1: Click and hold the channel/site users want.

Step 2: Drag and drop it onto the window that users want to assign in.

Resort/Remove Display Window Grids

Right-click on any channel and select <Re-sort> to rearrange camera images of connected sites in order, up to 512 channels.



Alternatively, users can also remove any channel by right-clicking on the grid and select <Remove>. Or users can select any grid and press <Delete> key on the keyboard to remove the channel.

Note that clicking <Re-sort> will restore the removed channels, or users can add the channels back to any grid via drag and drop.

NOTE: These functions will not be accessible in sequence mode.

Save Layout Files

The layout arrangement can be individually memorized for each connect group. Also, CMS will keep the layout arrangement when it's closed and restore the same layout when it starts up again.

Each login account can save its own layout files. Right-click on any mode icons and the pull-down menu will be shown as on the right. After selected <Layout file> the setting window will be displayed, as below:





The layout files are for backup or other users' use. Once users entered the file name and clicked <Save>, the new layout file will be shown on the file list. To delete a layout file, select a layout file from the list and click <Delete>, or press the "Delete" key on the keyboard. A message will be displayed to confirm the deletion.

To load a layout file, select a file and click <Load>, or double click on the file.

Show Covert Camera Images

If a camera is set to covert at DVR site, right click on the grid and select <Camera cover (On/OFF)> to un-covert at CMS site. Then video stream will come in, and an icon " " will be shown at bottom-left of the grid. The icon represents that the camera is covert at DVR site.



This function is only available when CMS and DVR site are logged in using accounts with administrator authority.

7.2 Camera Setting / Camera Info.

Configure Camera Setting

Camera setting can be configured by right clicking on a site and select <Camera Setting>.



Camera viewing setting enables users to set the display of *Site Name*, *Channel Name*, or *Time* on the top-left corner of the image.

Camera sound notification enables preset sound file to be played when an alert event occurs. It can be set via Site Base or Channel Base.

Setting via Channel Base

Select <Channel Base> from the menu and click <Load> to select a sound file. Then click <OK> to save the setting. Next right click on a channel grid to apply the sound setting by selecting <Sound Notification(On/Off)> from the pull-down menu. Note a message window will arise if sound file is not selected yet.





Quick Hot Key:

Click a channel grid and press the following keys:

- Ctrl + n: Sound Notification ON
- Ctrl + f: Sound Notification OFF

NOTE: The sound files selected will be saved in CMS folder \Setting\SoundNotification\.

NOTE: On the top-left of the grid will show [SN] to indicate sound notification is turned on.

Setting via Site Base

Select <Site Base> from the menu and check the option <Sound Notification enabled for All Channel> and/or <Same sound for all sites> as needed. Click <Load> to select a sound file. Then click <OK> to save the setting. The sites have the option <Same sound for all sites> checked will play the same sound, and the latest set sound will be played.



Quick Hot Key:

1. Click a channel grid and press the following keys:
   - Ctrl + Alt + n: Sound Notification ON for all sites
   - Ctrl + Alt + f: Sound Notification OFF for all sites
2. Click a site in the Site Tree and press the following keys:
   - Ctrl + Alt + n: Sound Notification ON for the selected sites
   - Ctrl + Alt + f: Sound Notification OFF for the selected sites

View Camera Info

The Camera Info can be viewed both in CMS and CMS Player. Right click on any channel grid and select <Camera Info.> from the pull-down menu to view the information. Refer to the following for examples:

Camera Info of CMS



Camera Info of CMS Player



7.3 Display Mode

The available display modes are single channel, 4-windows, 9-windows, 16-windows, 25-windows, 36-windows, 49-windows, 64-windows, 8-windows, 10-windows, and 13-windows.

There are two arrow buttons at the left and right hand sides of the screen, as shown below. Click on the left arrow button to display images of the previous page. On the other hand, click on the right arrow button to display images of the next page.

To view in a single channel, double-click on the channel in the site tree or on the grid.

To view in multiple-window mode, right-click on the desired icon and a menu will be display as on the right. The selections are described as the following.



Select from preview dialog

Choose this option and the picture as below will be shown. When the mouse pointed to any item, the preview display will be shown on the right. Double click on any item to display it on the viewing area.

Select from page number

Choose this option and the picture as on the right will be shown. Select any page number to display the chosen page on the viewing area. Since the maximum channel connection is 512ch, the choices of page numbers for 4-windows display mode will be from 1 to 128. A control icon <X> is provided to exit without selection.



7.4 Zoom In/Out Control via Mouse

Both in CMS and CMS Player, zoom in/out can be easily controlled via mouse scroll wheel. Either in CMS or CMS Player, click on any grid that users wish to zoom in in the viewing area. Move the scroll wheel away from the user to zoom in and a screen will appear like in the following picture.

On the upper left-hand corner will a zoom-in multiple will be shown. The maximum multiple is X7. Also on the lower right-hand corner the position of current viewing area will be displayed, shown as an inner white rectangle, compared with the original screen, shown as an outer rectangle frame.

In addition, the viewing area can be dragged and moved by left-clicking and holding the mouse while moving. On a zoomed-in screen, the mouse pointer will change to and when the mouse is clicked the pointer will become to indicate that the image is dragged.

NOTE: This function is not available in Dome Camera Control mode. Scrolling the wheel of the mouse will zoom in/out the camera lens of the dome camera.

NOTE: This function will use up a lot of CPU resources. It is recommended not to open too many programs at the same time to avoid a crash of CPU.

7.5 Sequence Display

To start displaying the sequence list, click on the <Sequence> icon to start the sequence. The colour of the icon will change to red colour when the sequence mode starts. The initial display mode will be what was set in sequence setting (1*1, 2*2, 3*3, 4*4 or 5*5).

Another way to start displaying the sequence list is by right-clicking on the sequence icon and a list will be displayed as shown below. Move the mouse to any item and the preview window will be displayed on the right. This list gives choices to users to begin displaying the sequence from any item. Double click on the desired item to start sequence mode.



After the sequence is started, users can still change the split mode by clicking on the display mode icons for 2*2, 3*3, 4*4 or 5*5. However, the initial split mode set in <Sequence> will remain the same. Note that icons for 6*6, 7*7 or 8*8 will not be accessible because they are not allowed to be shown in sequence mode.

The following functions are disabled in sequence mode:

1. Right click to see channel menu
2. Zoom In/Out
3. Drag and drop channels or sites to the display grids
4. Remove any channel grids on the display windows

NOTE: If users enabled the <Event Full Screen> and an event is triggered while running the sequence, CMS will display event full screen. The sequence will not resume until event full screen ends.

Click on the <Sequence> icon or the <Live> icon to exit the sequence mode.

7.6 Adjust the Image

Both CMS and CMS player provide image adjustment function. Double-click on a channel, then right click on it. Select <Image Adjustment> from the pull-down menu, and the image adjustment window will be displayed. Users can change the brightness, saturation, hue, and contrast of the channel.




Image Adjustment
The following configurations are only applicable to CMS display and do not effect CMS recording data.
Brightness : 127
Saturation : 127
Hue : 127
Contrast : 127
Default

NOTE: The <Image Adjustment> option will only be available when viewing single-channel screen.

Click the <Default> button to reset the value to the original preset.

NOTE: The <Image Adjustment> function has no effect on the recorded video. Whatever changes made to the <Image Adjustment> will not be applied to the recorded video.

7.7 Playback Recorded Video

This function allows CMS users to retrieve and play videos stored in the connected DVR. Click on the <Playback> icon, a window will be displayed as below. <Valid Time> indicates that the connected DVR starts recording from a certain period of time and ends at a certain period of time.



The other way to display the above windwo is to right click on the site in the site tree and select <Playback> → <Remote Playback> from the pull-down menu.



Playback the video stored in HDD of the connected DVR

Follow steps below to playback the video stored in the connected DVR.

Step 1. First select <Playback> in "Function" area.



Step 2. Specify the starting time for playback in the "Selected time" area or by moving the arrow of the slider bar at the bottom. Then click <OK> to playback the video.



NOTE: The "Select time" and slider bar will show the stop time from the last playback, if playback of video was

previously accessed.

Save the *.drv files to the local computer

Follow steps below to save the video to the local computer.

Step 1. First select <Archive> in the "Function" area. Then the "Selected channel" area will be available for users to choose desired channels.



Step 2. Specify the Start Time in the "Selected time" area and click <set start> in the "Function" area. Then specify the End Time and click <set end>. Alternatively, use the slider bar to select start time and end time. Click <OK> and specify the filename of the DRV file. Then CMS will start to download the video data. Close the <Archive> window to exit.



Remote Playback of CMS Central Sites

If users selected remote playback of CMS Central sites, two extra options will be displayed as below. When CMS Central is recording from the connected DVRs, users can playback and archive directly from CMS Central. The steps are the same as described above.


Site: [01] 192.168.6.111 (192.168.7.148)
Valid time
Start: 2009/12/21 18:45:01, End: 2009/12/23 15:15:49
DVR
Central
Selected time
Start Time:
End Time:
2009/12/21
2009/12/23
18:45:01
15:15:49
Select channel
1
2
3
4
Select All
Clear All
Function
Playback
Archive
OK
Cancel

Playback video stored in the HDD of local computer

If users wish to playback videos that have already been saved to the local computer, please launch the CMS Player.

NOTE: The CMS Player can only be started through CMS. If users try to start up the CMSPlayer.exe, an error message will be displayed.

There are two ways to launch the CMS Player. One way is to click on the <CMS Player> icon. Alternatively, right-click on a site in the site tree and select <Playback> → <Local Playback>.



Then CMS Player will be displayed. Click on the <Open Video File> icon as marked below.



The "Playback Search" window will be displayed as below. The following steps will guide users to playback designated videos.



Step A. Select <CMS Data> and choose the CMS server & group. Alternatively, select <DVR Data> and allocate a folder containing DVR HDD files.

Step B. Select <Playback Video>.

Step C. Select the date of the designated videos. Today's date is in a blue box, the date with video data is highlighted in brown, and the selected date is highlighted in blue.

Step D. For playback of CMS Data, select sites. Click on <+\-> to select or deselect all sites. The selected site will change to grey colour. For playback of DVR Data, there is no need to select sites, since it's just the DVR itself.

Step E. Scroll the slider bar to zoom in/out the displaying time.

Step F. Point the cursor at designated time and double-click to start playback the video.

Step G. Click on the <Open Video File> button to search for videos via the file list. Users can also convert DRV files to AVI files here. Refer to the next page for instruction of conversion.

NOTE: The recorded video of the IP camera can only be played back by the CMS player. Some errors might occur if playing back with a DVR player.

Convert *.drv files to *.avi files

Click on the <Open Video File> button in the "Playback Search" window, then the "Select a folder" window will be displayed. On the top center of this window, select <Convert To AVI> and double-click on the file which users wish to convert. A "Conversion List" window will pop up and the file will be added to the list. The other way to add files to the list is to right-click on the file and select <Add To List> or <Add All To List>.



NOTE: The list can contain files from different folders.

The messages shown on the conversion list windows are very important. If the duration of a DRV file is less than 3 seconds, the file will not be successfully converted. In addition, a link is provided for users to download and install video codec in order to playback the converted AVI files.

If users wish to remove any file from the conversion list, right-click on the file and select <Remove> or <Remove All> to delete files from the list. Click <Convert> to start conversion of the files on the list.


Conversion List
(1).If the duration of a DRV file is less than 3 seconds, it will not be successfully converted to AVI file by the CMS Player.
(2).Please download and install the codec from http://www.filehippo.com/download_klite_codec_pack/3723/
N...
DRV File Name
Status
1 C:\Program Files\CMS\Archive\sample\sample_CMS01_Arc_Grou...
2 C:\Program Files\CMS\Archive\sample\sample_CMS01_Arc_Grou...
3 C:\Program Files\CMS\Archive\sample\sample_CMS01_Arc_Grou...
Remove
Remove All
Convert

A small window will be displayed as on the right to show the progress of conversion. If users wish to terminate the conversion, click <STOP> to abort.



If the conversion is aborted, the status column will show "Break Off" for the specific file aborted. If the file failed to be converted, the status column will show "Fail".


Conversion List
(1).If the duration of a DRV file is less than 3 seconds, it will not be successfully converted to AVI file by the CMS Player.
(2).Please download and install the codec from http://www.filehippo.com/download_klite_codec_pack/3723/
N...
DRV File Name
Status
1 C:\Program Files\CMS\Archive\sample\sample_CMS01_Arc_Grou... Done
2 C:\Program Files\CMS\Archive\sample\sample_CMS01_Arc_Grou... Break Off
3 C:\Program Files\CMS\Archive\sample\sample_CMS01_Arc_Grou...
Convert

If the conversion is completed, the message as on the right will be displayed. The converted files will be stored in the folder specified in file path setting of CMS Player.



For more information about other CMS Player operations, please refer to the **Appendix A**.

Install required codec to playback converted AVI files

In order to correctly play back converted AVI files, install the K-Lite Codec Pack and select the codec options as described below.

1. Check <Mu-law, A-law> & <MS ADPCM> under <Other audio formats (ffdshow)>.


Setup - K-Lite Codec Pack
Select Components
Which components should be installed?
Select the components you want to install; clear the components you do not want to install. Click Next when you are ready to continue.
Custom Selection
CoreAAC 0.4 MB
Other audio formats [ffdshow]
AMR
IMA ADPCM
QDM2, MACE
IMC, MS GSM, Truespeech, True Audio, Nellymoser
Mu-law, A-law
MS ADPCM
DirectShow audio parsers: 2.6 MB
Current selection requires at least 37.9 MB of disk space.
< Back
Next >
Cancel

2. Check <Microsoft> for <AVI splitter> under <DirectShow source filters:>.


Setup - K-Lite Codec Pack
Select Components
Which components should be installed?
Select the components you want to install; clear the components you do not want to install. Click Next when you are ready to continue.
Custom Selection
AMR 0.3 MB
DirectShow source filters: 4.7 MB
AVI splitter
Microsoft
Gabest 0.4 MB
Haali 0.9 MB
MP4 splitter 0.9 MB
Haali 0.9 MB
Gabest 0.5 MB
Current selection requires at least 37.5 MB of disk space.
< Back
Next >
Cancel

7.8 Configure the OSD Menu of the Connected Site

The OSD menu of the connected site contains a list of items that are used to configure the connected site.

Right-click on the **Site** and select <Configuration> to open the OSD menu.

When the mouse was not clicked or the keyboard was not typed for 5 minutes, the configuration window will be closed automatically.



The OSD menus for DVR, IP camera, and Video Server are different from each other. Refer to the following for examples.

OSD Menu of a DVR

The pop-up window will show the OSD Menu of a DVR. Some items are not available in CMS setting condition. Please refer to the user's manual and OSD setup manual of the DVR for detailed instruction.



OSD Menu of a IP Camera

Clicking on the button <Link to WebPage> on the right at the bottom will initiate a user´s default browser to access the IP Camera's webpage. For detail instruction of OSD Menu settings, please refer to the user's manual of the IP Camera.



OSD Menu of a Video Server

Please refer to User's Manual of the Video Server for detail instruction.



7.9 Search for Event Videos

CMS can playback and archive event videos stored in connected DVR and CMS Central. Right click on the **Site** and select <Event Search>, then the <Event Search> window will be displayed.



Users can scroll down the event list to look for target event video. If the connected DVR has installed the POS module, users can either search by event or text.

Playback the event video from directly connected DVR

In <Search By Event> tab, select <Play Event> and double click on any item to playback the event video. The <Search By Text> tab allows users to search for text event videos of POS installed DVRs.





Playback the event video from CMS Central

In the <Search By Event(DVR)> tab, users can search and playback the event video stored in the DVR site. In the <Search By Event(Central)> tab, users can search and playback the event video stored in CMS Central. The <Search By Text> tab is the same as on the previous page, which retrieves data from the DVR site.



NOTE: CMS Central does not support the <Search By Text> function.

Archive the event video

Select <Archive Event> and press the "Ctrl" key to select multiple event videos to be archived. The maximum items can be selected is 1,000, which is the capacity of the list.



Click on <Start Archive> and an <Event Archive> window will pop up. The progress bar shows current downloading position. The status column shows the event is in "Archive", "Wait", or "Done" condition.

NOTE: The event archive or normal video archive for different sites can be performed simultaneously.

7.10 CMS Motion Detection

Users can set up motion detection at CMS site independently. Right-click on a preferred grid and select <Intelligent Surveillance> → <Motion Detection> from the pull-down menu.



The motion detection setting window will be shown as below.



Users can choose to monitor the complete screen or select up to 8 boxed areas after clicking on <Regional>. Click on <Clear> button to delete all selected areas. Alternatively, right-click on any selected area to delete it individually.

Refer to the following for description of motion detection settings.

Enable Function: Check on it to start monitor motion detection.

Motion recording: Check on it and CMS will record event video when motion is detected. The length of event video will follow <Event Recording Duration> specified in Event setting.

Show Motion Detection Region: Check on it to display the detection area visually on the monitoring screen. The boxes will also be captured and displayed on the snapshot images.

Start Simulation: Click on it to start simulating motion detection. As shown above, red boxes will mark the motion areas.

Stop Simulation: Click on it to stop simulation.

Sensitivity: Set up a desired sensitivity level.

Click on <OK> to apply the settings, or click on <Cancel> to disregard and return to Live mode.

NOTE: When motion alert is triggered, an alert icon " " will be displayed at bottom-left of the grid.

7.11 Missing/Foreign Object Detection

The purpose of Missing/Foreign Object Detection function is for users to keep an eye on the important objects and areas. Right-click on a preferred grid and select <Intelligent Surveillance> → <Missing/Foreign Object Detection> from the pull-down menu.



The object detected search window will be shown as below.



Users can set up up to 8 monitoring areas. Click on <Clear All> button to delete all boxes. Alternatively, right-click on any single box to delete it individually.

Sensitivity: Set up a desired sensitivity level.

Interval: The time specified here is for determining the lost of objects. If an object is removed from the selected areas for more than the time specified here, lost of object alert will be triggered.

Enable Function: Check on it to enable missing/foreign object detection.

Show Region: Check on it to display the detection area visually on the monitoring screen. The boxes will also be captured and displayed on the snapshot images.

Clear All: Click on it to clear all selected boxes.

Apply: Click on it to save and apply settings in the configuration section.

Start Simulation: Click on it to start simulating object detection. As shown in the previous page, green boxes will mark the lost of objects.

Stop Simulation: Click on it to stop simulation.

Live: Click on it to restore the Video Preview frame to live image.

Lost of Object Alerts

When lost of object alerts are detected, restore the object detected search window and the list on the left-hand side will show area number and time of the lost of object alerts.

If the connected site is a DVR, double-click on any item to playback video that is 15 seconds before the alert triggered. However, if the video is not added to the database yet, an error message will be displayed.

NOTE: Only the configuration of area positions, sensitivity, and interval will be permanently saved. The default image will be replaced by the initial image every time when CMS restarts. Therefore, please check the configuration every time CMS starts up.

NOTE: CMS Player also has a Missing/Foreign Object Detection function, and it is slightly different from what is in CMS. Refer to the appendix A for more details.

Click on <OK> to apply the settings, or click on <Cancel> to disregard and return to Live mode. The selected boxes will not be shown on the live monitoring screen.

NOTE: The "Motion Detection" function and "Missing/Foreign Object Detection" function can be enabled simultaneously.

7.12 Counting Application (PRO Version Only)

Counting Application enables users to keep tracks of object entrance/exit at designated positions. Right-click on a preferred grid and select <Intelligent Surveillance> → <Counting Application> from the pull-down menu.



The counting application setting window will be shown as below.



Refer to the following for a description of the counting application settings.

Enable Function: Check on it to enable counting application.

Show Virtual Line: Check on it to display the virtual line on Live monitoring display.

Virtual Line: Click to select this and users can draw virtual lines at preferred positions. After a virtual line is drawn, a window will pop up as shown on the right. Users have to define the In/Out direction and the monitoring type. A maximum of 10 virtual lines can be defined for each camera.



Object Size: After the virtual line is drawn, users need to define the size of the detected object. Click and drag the mouse to define a preferred object size.

Recounting Interval: Users need to specify the duration of the time segment. The In/Out counting numbers will be reset for each time segment.

Start Simulation: Click on it to start simulating the counting application. The In/Out counter will show numbers of detections.

Stop Simulation: Click on it to stop the simulation.

Clear All: Click on it to clear all defined virtual lines and the object size box.

Sensitivity: Set up a preferred sensitivity level.

Show Log: Check on it and the log will be displayed as shown on the right.



Clear Log: Click on it to clear the log.

Click on <OK> to apply the settings, or click on <Cancel> to disregard and return to Live mode.

NOTE: The Counting Application function is also available in CMS Player. The setting options are exactly the same as in CMS.

7.13 Cross Line Alert (PRO Version Only)

Users can use the Cross Line Alert function to monitor a prohibited entrance/exit at a designated boundary line. Right-click on a preferred grid and select <Intelligent Surveillance> → <Cross Line Alert> from the pull -own menu.



The cross line alert setting window will be shown as below.



Enable Function: Check on it to enable the cross line alert function.

Show Virtual Line: Check on it to display the virtual line on the Live monitoring display.

Record: Check on it to trigger the event recording whenever a cross line alert is detected.

Virtual Line: Click to select this and users can draw virtual lines at preferred positions. After a virtual line is drawn, a window will pop up as shown on the right. Users have to define the In/Out direction and the monitoring type. A maximum of 10 virtual lines can be defined for each camera.



Object Size: After the virtual line is drawn, users need to define the size of the detected object. Click and drag the mouse to define a preferred object size.

Start Simulation: Click on it to start simulating the counting application. The In/Out counter will show numbers of detections.

Stop Simulation: Click on it to stop simulation.

Clear All: Click on it to clear all defined virtual lines and the object size box.

Sensitivity: Set up a preferred sensitivity level.

Click on <OK> to apply the settings, or click on <Cancel> to disregard and return to Live mode.

NOTE: When a cross line alert is triggered, an alert icon "" will be displayed at bottom-left of the grid.

7.14 Take a Snapshot

The Snapshot function is a simple screen capture tool. When users click on the <Snapshot> icon, it will capture the screenshot of the window that users are currently viewing. Users can save the screenshots to the default path "\CMS\Snapshot\" or the folder that users have previously set in the file path. Please refer to <Setup the File Path> for more information about changing the file paths.

There are 2 ways to take the snapshot. One is to click on the <Snapshot> icon, and the snapshot window will be displayed. Select <OK> to save the file.



The other way is to right-click on the window and to select <Snapshot>. Note that it will only capture the image of the selected channel. The file will be saved without displaying the image.

NOTE: The default image format is *.jpg. If users selected more than one file type and took the snapshot, users will get more than one file of the same snapshot image.

Please go to <Settings> to set up the snapshot file type.



7.15 2-Way Audio Talk

2-way audio talk function enables users to communicate with the camera side. Currently the only supported camera type is GCI-H0503B and a Video Server.

Right-click on the channel and select <Talk(On/Off)> from the pull-down menu.



If the talk function is successfully enabled, "Talk" will be shown on a buttom left of the image. Users can speak through the microphone now to communicate with the camera side.

Currently the supported 2-way audio types are:

Camera Type	Audio Type
Video Server	PCM audio type
GCI-H0503B	ALaw and uLaw audio type

NOTE: RTP OVER RTSP Stream Protocol of GCI-H0503B and all other audio types currently do not support 2-way audio.

NOTE: The communication mode is one to one. The Broadcasting function currently is not available.

7.16 Instant Record Function

While the videos are usually recorded to the connected DVR, users can also choose to instantly record current "Live" or "Playback" videos to the local computer.

Right click on the **Site** and select <Start Recording> to start recording, and select <Stop Recording> to stop recording.



If time difference between CMS and the recording site is more than 1 day, a message will be displayed as below.



When the channels are being recorded, the title of the channels will show a capital letter "R" ([R]) at the end. The recorded files will be saved to the default folder "\CMS\Record\".

If users want to switch between Live/Playback modes while CMS is recording videos, the recoding has to be terminated. A message dialog will be displayed for confirmation.

NOTE: In case of switching from "Live" mode to "Playback" mode, the recording will be resumed from stopping point once "Playback" mode is ended and returns to "Live" mode.

NOTE: If the connection to the recording site is disturbed and then reconnected, the recording will be terminated without resumption.

7.17 Dome Setting / Dome Control

Users can also set/control the dome camera in CMS. Right-click on the channel where a dome camera is properly installed. Refer to the following picture to see how they look like.



Dome Setting:

Select <Dome Setting> to set up the Dome ID or Dome Protocol. Note that the changed dome protocol at this interface is only temporary. To permanently change the dome protocol, please modify it in the configuration.

Dome Control:

The function of each button on the <Dome Control> panel is described below.

A.F. (Auto Focus)

Click on to focus the camera automatically.

Set/Go Preset Point

Click on to set a present point, and to go to the preset point.

ID

Click on to set up the Dome ID/Protocol. This function resembles the <Dome Setting>.

Focus

This is used to manually focus on the objects. Click on the <Focus Near> / <Focus Far> icons to adjust the focus.

Iris

This is used to set up the iris. Click on the <Iris Open> icon let in more light, or the <Iris Close> icon to reduce the light.

Zoom

This is used to zoom in/ out to the object. Click on the <Zoom In> / <Zoom Out> icons to adjust. It can also be adjusted by scrolling the wheel of the mouse. The CMS zoom function will be disabled in dome camera control mode. Scroll towards the user to zoom out and away from the user to zoom in.

Direction Button

Click on the arrows to pan and/or tilt the dome camera.

Speed Slider Bar

The slider bar is used to adjust the speed of the pan/tilt movement. 0 is the slowest and 100 is the fastest.

Mouse Control

If the mouse is moved to the top/ bottom/ left/ right edge of the scren, a red triangle as in the picture on the right will show up. At this time left-clicking the mouse can move the screen towards the direction where the red triangle points to. Zoom In/ Out by using the scroll wheel of the mouse.

NOTE: The <Dome Control> panel is different if the dome camera is connected through a Video Server. Refer to the following figures for detailed information.

There is an extra button (as circled in the picture on the right) that allows users to enter and edit the OSD setup menu of the Video Server Camera.



Click on <Enter> at the center of the button to display the OSD setup menu on the camera screen. Then click on the arrows to make selection and changes.

7.18 Schedule Record Function

Users can schedule a specific time to record the videos to the local computer. Schedule Record window will be displayed after clicked on the <Schedule Record> icon.

The current setting site will be shown on the top of the Schedule Record window, as circled in the picture below. Alternatively, users can click on the <Select All> or <Clear All> buttons to set up all sites to always record or always not record at once.



The scroll-down menu circled below shows the recording types.



<OFF>
Select this to switch off the schedule record function.

<NORMAL AND EVENT>
Schedule to record both the normal and event videos within the selected time frame.

<EVENT ONLY>
Schedule to record only the event videos within the selected time frame.

The scroll-down menu circled below shows the selecting options.



<SELECT CELL>
Choose this to select any cell from the table.

<CLEAR CELL>
Choose this to clear any cell from the table.

<SELECT ALL CELL>
Choose this to select all cells from the table.

<CLEAR ALL CELL>
Choose this to clear all cells from the table.

Follow the steps below for an example of setting a schedule record for CMS.

Schedule Recording Times

Step 1. Select a site or a channel from the box on the right by a single click. When a site is selected, the same setting of schedule record will be applied to all channels. Click on a channel to set a unique schedule record for the particular channel. In this example, the schedule of a site will be set. Select a site in box 1, and set the recording option to <NORMAL AND EVENT> in box 2.



Step 2. Assuming that the site will be scheduled to start recording video from 2:00 to 4:30 on Tuesday and Wednesday. Since the duration of each cell is 30 minutes, click on the cell under 02 for Tuesday and drag to the cell under 04 for Wednesday; and the colour of the cells will be changed to purple indicating that both normal and event videos are going to be recorded during the selected times.



Step 3. After the time frames are selected, click <OK> to save and exit the Schedule Record window.

Cancel Scheduled Recording Times

If users want to cancel a time frame from selected schedule, for instance, 3:00~3:30, set the selecting option to <CLEAR CELL> in box 1. Click and drag the cells under 03 from Tuesday to Wednesday. The cells will be blank which indicates that CMS is not going to record anything. Click on <OK> to save and exit the Schedule Record window.



Select/Clear All Cell

If users want to set the schedule to record at all times, click on the circled blank cell located on top left corner of the table or set the selecting option to <SELECT ALL CELL>. If users want to reset the schedule of the site, set the selecting option to <CLEAR ALL CELL>. Click on <OK> to save and exit Schedule Record window.



Select/Clear Cell by Date/Time

Another way to select or clear the time frame is by clicking on the Day or Time tabs. For example, when users click on the <Tue> tab, the colour of all Tuesday cells will be changed and the site is scheduled to record normal and event videos every Tuesday. When users click on 5:00~5:30 tab, the colour of all 5:00~5:30 from Monday to Sunday will be changed. Click on <OK> to save and exit Schedule Record window.



Special Schedule of a Specific Date

If users wish to set up a special schedule for a specific date, simply select a date from the pull-down menu of <Holiday Setup> and click on the <Add> button. At the bottom of the <Schedule Record> window, users can find a new row of the added date as shown below. Set up the schedule for that date, and the schedule record will only run once for that special day.



7.19 E-MAP Function

E-MAP is a function that allows users to illustrate the positions of the cameras on a self-selected image. Click on the <Emap> icon to open the E-MAP window. Please follow the steps below to set up the E-MAP.

Step 1. First load an image file by clicking on the <Load Image> icon.



NOTE: The image shown in the window is the default picture. It will only be available when default is installed.

Step 2. The figure below is the Load Image window to add or delete images, and undo or confirm settings. Click on <Add> to add an image. Note that E-MAP only supports *.bmp, *.jpg, and *.gif files.



Step 3. After the image is added, the filename of the image will be displayed on the list. Index indicates the order, starting from "0", of the files. After the image is loaded, click <Ok> to confirm and save the setting.



Step 4. Select the image file that was loaded to E-MAP from the scroll menu <Please Select Image>.

Step 5. The chosen image will be displayed in the E-MAP main window. The image of a grocery store is used in the following example. Drag and drop a channel from the site tree to any desired position of the image.



Right-click on a camera icon can remove it or rotate its pointing direction, including North, Northeast, East, Southeast, South, Southwest,



West and Northwest.

Step 6. When the mouse pointer moves over a camera icon in the image, an information dialog box will be displayed as in the picture below marked with #1.



Double-clicking on any camera will display the live preview image of the camera. When a camera icon is clicked, the camera live preview window will be highlighted if it has been displayed, as in the picture above marked with #2. Otherwise, the corresponding channel in the site tree will be highlighted as shown in picture below.



NOTE: The camera live preview window is limited up to three instances at the same time.

Step 7. Right-click on the camera preview window to display the camera control menu. The menu items include: Snapshot, Talk(On/Off), Dome Setting, Dome Control, Sound Notification(On/Off), and Camera Info.

Camera Icons

There are three different types of camera icons in E-MAP: dome camera, fixed camera, and alert icons.

Dome Camera icon

Fixed Camera icon

Alert icon

The Dome camera icon will be displayed when the selected camera is a PTZ (pan/tilt/zoom) dome camera, i.e. GCI-C0735P and GCI-C0745P. The Fixed Camera icon will be displayed when the selected camera is a fixed camera. The Alert icon will be displayed when an alert is triggered to the camera on the image. The alert icon will blink to attract attention.

Change the Emap Size

Users can adjust the display size of the image on E-MAP by clicking on the icons described as below.

<Original>: To display the original size of the image.
<Double>: To double the size of current displayed image.
<Half>: To reduce the current displayed image size by one half.
<Fill>: To adjust the image to fit the display window (refer to the picture on the right).

NOTE: If there is no image file loaded on the Emap window, an error message will be shown when clicking on any of the four buttons above.

NOTE: When the image is very large, or when users cannot see the entire image in the display window on the right, click on a channel in the site tree and the E-MAP will automatically move to the location of the selected channel.

The Google Map Function

With the Google Map function, users can mark the locations of loaded emaps on Google map. Refer to the steps below for details.



Step A. Click on the <Google map> icon and Google map will be displayed.

Step B. The loaded emaps will be listed here.

Step C. Type the name of the location and click on <Search>. If Google map is able to find the target location, it will be shown at the center of the Google map. The display size of the Google map will not be changed.

Step D. Click on the directional icons to move the Google map to preferred directions. Click on the center icon to return to the last view.

Step E. Click on +/– to magnify/shrink the display size of the Google map. Alternatively, drag the slider bar to select a preferred display size.

Step F. Select a preferred type of the Google map. "Hybrid" is the mixture of a pure map and a Satellite map.

Step G. Click and drag the emaps to the target locations. A balloon with a letter will be displayed to mark the location of each emap. Users can always click and drag balloons to change their locations. Right -lick on any balloon and select <Remove this map> to delete the mark.

NOTE: Double-click on any balloon and the emap will be displayed. Alternatively, the emap can also be restored via double-clicking on the emap icon listed in the site tree.

7.20 Health Function

This is a function that verifies the HDD status of the DVR sites in the current connected group. Click on the <Health> icon and a progress bar will be shown to indicate that the information is being retrieved. The following picture is an example. Note that if IP cameras do not have a connected HDD, they will not be shown in the chart.



The information items shown in the chart are described below:

Device Name

This item shows the model name of the HDD.

Internal/External

This item indicates whether the HDD is an internal or external device.

Total Size

This item indicates the total size of the HDD.

Active/Non Active

This item indicates whether the HDD is active or non-active.

Temperature

This item indicates the current temperature of the HDD in Celsius degree.

NOTE: Temperature data is not retrievable for some specific models. In the Temperature column, it will show "Not available".

7.21 Lock Function

The Lock function allows users to protect CMS from unauthorized use when there is need to be away from the computer for a while. Closing CMS is not allowed and other functions will be limited as described below.

Click on the <Lock> icon and a confirmation message will be displayed as on the right. Click "Yes" to confirm.



After users clicked "Yes", the icon will be changed to show that CMS is currently being locked. When users click unlock, the window as shown on the right will be displayed for users to enter the username and password to unlock.



To unlock, the following are two scenarios:

	Login Account	Unlock Account	Note
1	User	- Login User - Any Administrator	The access authority will still be the User's limit.
2	Administrator	- Login Administrator	If the password is changed, use a new password to unlock.

When CMS is locked, windows control will be as the following two types:

	Type	Example	Windows Control
1	Setting	Setting, Schedule Record, Emap, Dome Control, etc	The windows will be closed without saving changes. It is recommended to save settings before locking up CMS.
2	Monitoring	Archive, Alert, etc.	It is not allowed to close the window but just to minimize it.

NOTE: If CMS is forced to be closed while it is locked, the CMS system will still be locked when it is started up again.

NOTE: If the password of the current login account is changed, use the new password to unlock.

7.22 Joystick Control Function

When a joystick is connected, it can work in Mouse Control mode and Dome Camera Control mode. Refer to the picture on the right for a sample of a joystick. The requirement of the joystick is as the following:



1. 12 buttons
2. X, Y, and Z axis

Press button "8" to change between mouse or dome camera control modes. However, if the selected camera is not a dome camera, the joystick can only be in Mouse Control mode.

NOTE: Only the first launched CMS server can use joystick control function.

When CMS detects an available joystick, the CMS icon in the system tray icon will change to a joystick icon. In addition, a message will be shown to tell the current control mode: mouse control or dome camera control. Right-click on the joystick icon and a menu will be shown as on the right. Select <Joystick control (On/Off)> to switch on/off joystick control.



Select <Show joystick function> will display a hint screen showing functions of the keys according to the control mode, either mouse control or dome camera control.

Whenever the joystick control mode changes, a message will be shown at the system tray to inform users. Refer to the following tables for the controlling options:

Under Mouse Control Mode

X axis	Left / Right movement
Y axis	Up / Down movement
Z axis	Clockwise to speed up; Counterclockwise to slow down movement
8	Change to Dome Camera Control mode
11	Left-clicking key
12	Right-clicking key

Under Dome Camera Control Mode

X axis	Move dome / OSD menu selecting left or right
Y axis	Move dome / OSD menu selecting up or down
Z axis	Clockwise to zoom in; Counterclockwise to zoom out
1	Slow down movement
2	Speed up movement
3	Focus Far
4	Focus Near
5	Iris Close
6	Iris Open
7	Auto / Manual Focus
8	Change to Dome Camera Control mode
9	Enter OSD Menu (IP Dome)
10	Function as ENTER key in OSD Menu (IP Dome)
11-12	No function

Appendix A: CMS Player

CMS Player is a compact version of the standard DVR Player. When multiple CMS instances are opened in multiple monitors, each CMS can launch 1 CMS Player. The main window of CMS Player is shown below with the name of the buttons.



1	Slider Bar
2	Playback Speed Indicator
3	Site Tree
4	Audio
5	Display Modes: 2X2, 3X3, 4X4, and FULL SCREEN
6	Open Video File, Frame View Setting, File Path Setting, and Snapshot
7	Playback Controls: Fast/Step Backward, Play/Pause, and Fast/Step Forward

The usage and function of each button will be described in the following paragraphs.

Slider Bar

Click and drag the bar to search through the video.

Playback Speed Indicator

The Speed Indicator shows playback speed in forward or backward direction.

- ">" indicates forward playback while "<" indicates backward playback.
- The playback speed can be *1, *2, *4, *8, *16, or *32.

Site Tree

The site tree shows the channels of the opened DRV file. Double-click on a channel to view the selected channel in one screen. By right-clicking on the site tree users can choose to expand or collapse the site tree.



Audio

Click on the <Audio> icon located underneath the site tree to enable or disable the audio of the opened DRV file.

Display Modes

Click on the <2X2>, <3X3>, or <4X4> icons to view the camera images in multiple window mode. Clicking on the <FULL SCREEN> icon will enlarge the CMS Player window to fit the full screen. Click on the <FULL SCREEN> icon again or press <Esc> key on the keyboard to return to normal screen mode.

NOTE: Image Adjustment and Camera Info are described in the previous sections. Missing/Foreign Object Detection will be introduced later on.

Open Video File

Click on the <Open Video File> icon to display the "Playback Search" window. Users are allowed to playback, export, or delete videos. The instruction of video playback is illustrated in section ***Playback Recorded Video***. The following will be details about video exportation and deletion.

Export Video:

Refer to below for steps of video exportation.



Step A. Select <CMS Data> and choose the CMS server & group. Alternatively, select <DVR Data> and allocate a folder containing DVR HDD files.

Step B. Select <Export Video>.

Step C. Select the date of the designated videos. Today's date is in a blue box, the date with video data is highlighted in brown, and the selected date is highlighted in blue.

Step D. Click and drag the cursor to select the designated videos.

Step E. The start and end time of the selected video will be displayed here.

Step F. Click on the <Start> button. A window will pop up, and users are allowed to enter a filename and select the video type (AVI or DRV) through the window. Then click on <Save> to start the exportation.

Delete Video:

Only when the current CMS login account is in the admin group, will the video deletion function be available. Refer to the following for step by step instruction.



Step A. Select <CMS Data> and choose CMS server & group. Note that DVR data does not support purge function.

Step B. Select <Purge>.

Step C. Select the date of the designated videos. Today's date is in a blue box, the date with video data is highlighted in brown, and the selected date is highlighted in blue.

Step D. Click and drag the cursor to select the designated videos.

Step E. The start and end time of the selected video will be displayed here.

Step F. Click on the <Start> button and a confirmation dialog will be displayed. Enter the correct username and password to start the deletion.

Event List:

In addition, users can also playback and export event videos via searching through the event list. Click on the <Event List> button on the upper right hand corner of the "Playback Search" window. The "Event List" window will be displayed as on the right. Refer to below for the instruction.



First set searching criteria in Box A and click on the <Search> button. The event videos satisfying the searching criteria will be listed in Box B. If the list contains more than 1000 event videos, click on the <Previous> and <Next> buttons in Box D to see more selections.

In Box C, users can choose to playback or export event videos. Select <Play Event> and double-click on any item in Box B to playback the event video. Alternatively, select <Export event> and a <Start> button will appear at the bottom. Press the Ctrl key to select multiple files and click on the <Start> button to begin exporting the event video(s).

NOTE: For event search of DVR data, the <CMS>, <Group> and <Site> in Box A will be inaccessible.

Video Type Display:

The chart in the middle of the "Playback Search" window allows users to assign unique colour displays to represent different types of video data. Double-click on any cell under the "Colour" column and choose a preferred colour to represent the corresponding video type.



Frame View Setting

Users can choose to show/hide the time and alert text on the video.

Click on the <Frame View Setting> icon, and the View Setting window will be displayed. Check <Show Time>, and the time will be shown on the screen. Check <Show Frame State>, and the alert icon will be displayed at bottom-left. Uncheck to hide the information.

File Path Setting

Click on the <File Path Setting> icon to preset file paths for AVI conversion files and snapshot files. Click on <Browse> to select desired folders. In addition, the file type of the snapshot pictures can also be selected: Bmp, Jpg, Gif, or Tif formats. After the settings are selected, click on <Save> to save.



Snapshot

Click on the <Snapshot> icon to capture a snapshot of the screen. When the snapshot window is opened, users can choose to rename the filename or leave it as it is. Click on <OK> to save the snapshot or <CANCEL> to discard it.



Playback Controls

Play/Pause:

Click on to start playing back the video. The icon will change to showing that the video is now playing. Click on to pause playing back the video.

Fast/Step Backward:

Click on to play the video fast backward. When the playback of the video is paused, click on this icon to move one step backward.

Fast/Step Forward:

Click on to play the video fast forward. When the playback of the video is paused, click on this icon to move one step forward.

Missing/Foreign Object Detection



Right-click on any grid with video and select the option <Missing/Foreign Object Detection>. The basic configuration of the Missing/Foreign Object Detection function in the CMS Player is the same as what is in CMS. Please refer to section ***Missing/Foreign Object Detection*** for more details. This section will introduce the different parts of the Missing/Foreign Object Detection function in the CMS Player.



Quick Search: Click on it to quick-skim through the video for object search of the selected area(s). The list will be filled when foreign or lost object alert(s) are found.

Stop Quick Search: Click on it to stop the quick search.

Assign a Channel to Certain Grid

Similar to CMS, CMS Player also allows users to assign any channel in the site tree to any grid of the CMS Player main window. Follow the steps below to complete the assignment.

Step 1: Click and hold the channel which users want.
Step 2: Drag and drop it onto the window that users want to assign in.

Resort/Remove Displaying Grid

Right-click on any channel and select <Re-sort> to restore the original layout.



In addition, users can also remove any channel by right-clicking on the grid and select <Remove>. Alternatively, users can select any grid and press <Delete> key on the keyboard to remove the channel.

NOTE: Selecting <Re-sort> will restore the removed channels, or users can add a channel back to any grid via drag and drop.

Image Adjustment

The Image adjustment function in the CMS Player is the same as in CMS. Please refer to section ***Adjust the Image*** for more details.



Camera Info

The Camera Info function in the CMS Player is the same as in CMS. Please refer to section ***Camera Setting / Camera Info*** for more details.

Counting Application (PRO Version Only)

The Counting Application function in the CMS Player is the same as in CMS. Please refer to section ***Counting Application (PRO Version Only)*** for more details.

Appendix B: Troubleshooting

The following are some common situations when users are having difficulty with the CMS server.

1. CMS server does not work properly. How can it be recovered or where can I ask for help?

   Please try the following ways to recover it first.

   A. Please check if the computer meets the system requirements.

   B. If CMS automatically closes when it is starting up or connecting to sites, please send the files stored in \CMS\Setting\ under improper operation condition. Afterwards, re-install CMS and check to install **Default Setting** during installation. Remember not to import old setting files. This will tell whether the old setting data are corrupted.


CMS Setup: Installation Options
Check the components you want to install and uncheck the components you don't want to install. Click Next to continue.
Select components to install:
Microsoft VC 2008 SP1 Redistributable Pack
CMS (Required)
Start Menu Shortcuts
NTP (Network Time Protocol) Server
Default Setting (Old setting will be deleted!
Ext2Fsd (ext2 file system driver for Windo
Space required: 125.9MB
Cancel
Nullsoft Install System v2.45
Next >

   C. If CMS cannot successfully connect to sites, check the following.

   - Confirm IP, port, username, and password of the site. Users can connect to the site via IE browser to verify the site exists and is connectable.
   - Close the firewall and virus scan software and try to connect again. If the problem is due to the firewall or virus scan software, please change their settings.
   - If the connection still fails, please send the IP address to one of our engineers.

NOTE: When users need to ask for an engineer's help, please send a copy of the files stored in \CMS\Log\ as well.

2. CMS server takes up too much HDD space.

   We have found that the preset of the virus scan software "NOD32" will automatically create a temporary file under the windows system temporary folder when CMS connects to sites. This temporary file will automatically increase the size which causes the HDD to lack space.

   Please go to the control center of the NOD32 and disable **IMON**. Then the problem should be resolved. The following pictures are examples.



3. The PC crashed while playing back the AVI file exported from the DVR or converted by the CMS Player.

   Click the <Start Menu> and select <Run>. Then input "cmd regsvr32 /u shmedia.dll" and click <OK>. Playback the AVI file again and the problem shall be solved.